

Your OCCSensaBLE™ Occupancy Sensor



IMPORTANT: YOU HAVE 24 HOURS!

Once power is supplied to the luminaire, you have 24hrs to adjust the sensor's factory settings. After 24hrs, adjustment requires power cycling. Read below, carefully. It is highly recommended to download the OCCSensaBLE app [before](#) supplying power.

General

OCCSensaBLE is controlled via the native mobile app, available for download for Android® & iOS®

Adjustable settings can be configured as needed for specific applications. **Wireless** e-configuration requires the app to address each individual luminaire. **The sensor will default to the following factory settings if no configuration steps are performed:**

- The luminaire will operate in occupancy sensing mode from Dusk to Dawn (will turn on at Dusk/off at Dawn)
- When motion is detected, the luminaire will operate at 100% output
- After 5 minutes with no motion detected, the luminaire will return to 30% output level

Security

After power is supplied to the luminaire, as an initial security measure, OCCSensaBLE will stop broadcasting via Bluetooth™ after 24 hours. To reset and gain Bluetooth access to configure settings, power must be turned off/on.

When you create personalized settings, you can name and copy the settings as a profile and save it to a location. This action requires the use of a password. With this password, lights can be accessed and re-configured at any time *without* cycling power. For further details and tips, watch tutorials online at <https://vimeo.com>, and search "**occsensable**"